



No.	Part#	Part Name
1	JD-8812-01	Body
2	JD-8812-02	O-Ring
3	JD-8812-03	Union Nut
4	JD-8833-08	O-Ring
5	JD-2826-05	Spout Adapter
6	JD-2826-04	Retaining Ring
7	JD-8803A-14	O-Ring
8	JD-8821-06	Ceramic Cartridge
9	JD-8803A-15	Spout Nut
10	JD-9911-04	Lever Handle
11	JD-9700-05	Set Screw
12	JD-9911-05	Handle Base
13	JD-9911-08	O-Ring(Red)
14	JD-9911-06	O-Ring(Blue)
15	JD-8801-12	Aerator Assembly
16	JD-8801-13	Aerator Gasket
17	JD-8812-02	Spout
18	JD-8802-02	Lock Nut
19	JD-8802-03	Gasket
20	JD-9912A-01	IPS Adapter
21	JD-8802-05	O-Ring
22	JD-8802-06	Gasket